



Regulator: 1/8" Allen...screw all the way "in" for zero psi. Screw "out" to set psi @ 125 psi or whatever. Screw bottle to valve with the knob all the way open. Once the valve is tightened into place, tightening the knob will release the pressure from the bottle to the regulator.

To remove bottle open the knob all the way and unscrew the valve from the bottle.

Use 1/4" efi hose and clamps.